

Printer
ACTIVE WEAR



MEASUREMENT LIST

Brand: PRINTER ACTIVE WEAR

Style: **2261074 Airwalk Lady**

	XS	S	M	L	XL	XXL	3XL		
body lenght CB	62	64	66	68	70	72	74		
1/2 chest	46,5	49,5	52,5	56	60	64	67		
Sleevelenght	63	64	65	66	67	68	69		

All measurements are indicative with minimum tolerance of 1 cm